

DOOR AND FRAME PREPARATION/TEMPLATE INSTRUCTIONS

<p>① MARK CENTERLINES</p> <p>Mark the horizontal centerline of the lock on both sides of the door and on door's edge.</p>	<p>② MARK DRILL POINTS</p> <p>Position the applicable Template on the edge and the sides of door. Mark holes for each side and top and bottom holes of mortise.</p>	<p>③ MORTISE AND DRILL HOLES</p> <p>Drill the holes that have been marked and mortise door - Reference applicable Templates, Sheets 1 &amp; 2, for hole dia/depth and mortise prep specifications.</p>	<p>④ INSTALL STRIKE - WOOD FRAME</p> <p>1074-2 STRIKE/DUST COVER ASSEMBLY SHOWN Prep door frame per applicable Template, Sheet 3, and install strike/dust cover assy.</p>	<p>⑤ INSTALL STRIKE - METAL FRAME</p> <p>1074-2C STRIKE/DUST COVER ASSEMBLY SHOWN Prep door frame per applicable Template, Sheet 4, and install strike/dust cover assy.</p>
---	---	--	---	---

HARDWARE INSTALLATION

<p>① INSTALL LOCK, REMOVE FACEPLATE AND SET ASIDE.</p>	<p>② INSTALL ADAPTOR SCREWS &amp; LEVER ASSEMBLIES</p>	<p>③ INSTALL THUMBTURN ASSEMBLY</p>	<p>④ INSTALL CYLINDER ASSEMBLY</p>	<p>⑤ INSTALL FACEPLATE</p>
--	--	-------------------------------------	------------------------------------	----------------------------