



**MOUNTING INSTRUCTIONS:**

TO LOCATE DOOR HOLDER PLACE THE DOOR IN THE POSITION WHERE IT IS TO BE HELD OPEN. THE LOCATION OF THE TOP 2 MOUNTING HOLES IS 4 5/8" FROM THE FLOOR, OR POSITION THE HOLDER AS SHOWN IN THE SIDE VIEW, BEING SURE THAT THE RUBBER SHOE IS FLAT ON THE FLOOR AND CENTER-PUNCH THE HOLE LOCATIONS. THE CENTERLINE OF THE HOLDER SHOULD BE ABOUT 8 INCHES FROM THE EDGE OF THE DOOR.

IF DOOR PIVOTS ARE WORN OR HAVE EXCESS PLAY, INSTALL HOLDER SO THAT THE RUBBER SHOE RESTS SLIGHTLY ON IT'S HEEL.

**NOTE:**

HOLES FOR MOUNTING MUST BE DRILLED AT THE JOB LOCATION TO INSURE PROPER LOCATION OF THE DOOR HOLDER DUE TO UNEVEN FLOORS.