



INSTALLATION INSTRUCTIONS:

1. REMOVE BACK PLATE (ITEM 1 ABOVE) BY UNSCREWING IT FROM THE BODY.
2. DRILL HOLE FOR PLASTIC BANTAM (SUPPLIED) WHEN LOCATION FOR BUMPER IS IDENTIFIED. USE A $\varnothing 1/4$ INCH DRILL BIT. INSERT BANTAM.
3. MOUNT BACK PLATE LOOSELY AND MARK SPOT FOR NAIL (SHOULD BE 1/4 INCH OVER FROM CENTER HOLE). REMOVE BACK PLATE.
4. DRILL HOLE FOR NAIL USING 3/32 INCH DRILL BIT.
5. REINSTALL BACK PLATE WITH SCREW (#6 X 1/2" FH PH WS) - SECURE TIGHTLY, INSERT NAIL (#16 X 5/8" PIN) INTO BACK PLATE INTO HOLE DRILLED FOR NAIL
6. SCREW BODY OVER BACK PLATE - MAKE SURE BUMPER IS INSERTED INTO BODY PRIOR TO INSTALLATION.

Rev Record:
PRODUCT TITLE: 1275RP WALL BUMPER WAS: 1275RP.XXX WALL BUMPER.
CHANGED NOTE 4. ADDED PLASTIC BANTAM, NAIL AND RUBBER BUMPER CALLOUT. SGH/JG, 09/02/15