

DOOR AND FRAME PREPARATION/TEMPLATE INSTRUCTIONS

<p>① MARK CENTERLINES</p> <p>Mark the horizontal centerline of the lock on both sides of the door and on door's edge.</p>	<p>② MARK DRILL POINTS</p> <p>Position Template on edge and side of door. Mark holes for each side and top and bottom holes of mortise.</p>	<p>③ MORTISE AND DRILL HOLES</p> <p>Drill the holes that have been marked and mortise door -reference applicable Templates, Sheets 1 &amp; 2, for hole dia/depth and mortise prep specifications.</p>	<p>④ INSTALL STRIKE - WOOD FRAME</p> <p>Prep door frame per applicable Template, Sheet 3, and install strike/dust cover assy.</p>	<p>⑤ INSTALL STRIKE - METAL FRAME</p> <p>Prep door frame per applicable Template, Sheet 4, and install strike/dust cover assy.</p>
---	---	---	---	--

HARDWARE INSTALLATION

<p>① INSTALL LOCK, REMOVE FACEPLATE AND SET ASIDE.</p> <p>To bevel lock, loosen adjustment screws at top and bottom of case, turn to desired bevel and re-tighten screws. Insert lock into cavity and fasten screws.</p>	<p>② INSTALL LEVER/ESCUTCHEON ASSEMBLIES</p> <p>(If lock indicator installed)</p>	<p>③ INSTALL CYLINDER ASSEMBLY</p> <p>"right hand shown viewing from inside"</p>	<p>④ INSTALL FACEPLATE</p>
--	---	--	----------------------------