



NOTE:

- 1) BOLT PREP: DRILL (& TAP) 2 HOLES IN DOOR FOR #8-32 OR #8 WOOD SCREW.
- 2) STRIKE PREP: DRILL (& TAP) 2 HOLES IN FRAME FOR #6-32 OR #5 WOOD SCREW.

 **Trimco**

TITLE No. **3999SE** FLUSH SLIDE BOLT
FOR WOOD DOORS

DATE 12-27-94

TEMPLATE NO. 11567A