



**INSTALL KIT
(PN FANTOM-INSTALL)**

This kit includes all tools (except power tools) required to install the Fantom Doorstop.



**SHIM
(PN FANTOM-SHIM)**

For use when doors have a gap exceeding 10mm. The shim brings down the height of the striker plate and magnet to achieve a lower gap.



**DIAMOND CORER
(PN FANTOM-TILE)**

For use when installing in a tiled flooring surface. The Diamond Corer allows for a clean, round 14mm hole to be drilled into tiled surfaces.



**MAGNET HOUSING
(PN FANTOM-ALUMDOOR)**

The Magnet Housing has been disguised to allow installation in hollow extrusion such as aluminum or steel framed doors. Can also be used on hollow core doors if necessary.



**CARPET PUNCH
(PN FANTOM-CARPET)**

For use when installing in a carpeted flooring surface. It allows for a clean, round 14mm hole to be punched into the carpet before drilling, removing the risk of threading the carpet with the drill bit.



**FACE MOUNT
(PN FANTOM-FACEMOUNT)**

Fantom Face-Mounts are designed for use when the installer does not wish to take the door off. Face-Mounts are ideal for use on front doors which often have thresholds and/or weather seals.

